





**COLOUR WHEEL****COL1**


0507K004  
CONV.FILTER CTO  
TC3256

**COL2**


0507K003  
CONV. FILTER CTB  
DL542

**COL3**

0507C046.D01  
WOOD SW 460

**COL4**

0507C051.D01  
ORANGE LW590

**COL5**


0507C042.D01  
GREEN WB5055

**COL6**

0507C047.D01  
RED LW 640

**COL7**

0507C041.D01  
DARK BLUE SW490

**COL8**

0507C053.D01  
AMBER LW 550

## **OPENING THE PROJECTOR HOUSING**

It is possible to inspect the inside of the projector by removing the cover as indicated below.

### **ATTENTION**

REMOVE MAINS POWER PRIOR TO ACCESSING THE PROJECTOR'S INTERNAL COMPONENTS.

- 1) Loosen the 3 (1/4 turn) screws which fix the head covers (photo 1) .
- 2) Once unscrewed, simply lift the covers to access the internal components (photo 2).

Photo 1



Photo 2

